



#930 TPO PRIMER

Premium Primer

- Eliminates The Need For Base Coat
- Water Based

#930 TPO Primer is a water based, clear, acrylic primer. It is formulated with a unique, premium acrylic resin that is designed to enhance the adhesion of acrylic coatings to aged TPO single ply membranes.

#930 TPO Primer eliminates the need of a special base coat that is required when applying acrylic coatings to TPO membranes.

NOT RECOMMENDED FOR USE OVER EPDM, PVC OR OTHER SINGLE PLY MEMBRANES.

#970 A2A

Bonding Primer Acrylic To Asphalt Clear Acrylic Primer

- Water Based
- Formulated For Smooth Asphalt Surfaces
- Ideal For Use With Ponding Conditions

#970 A2A Bonding Primer (Acrylic to Asphalt) is a water based, clear acrylic primer. It is formulated with premium acrylic resins that are designed to improve the adhesion of acrylic coatings to smooth asphalt products. #970 A2A Bonding Primer is designed to be used as a primer coat for ElastaHyde over smooth (non-granulated) asphalt roofing such as APP, SBS, Mopping Asphalt and Asphalt Emulsion. #970 A2A Bonding Primer also aids in the adhesion of the acrylic coating in ponding conditions over most substrates.



#950

Primer/Sealer/Stain Blocker

- Water Based
- Clear Acrylic Primer
- Blocks Asphalt Oils From Staining

#950 Primer/Sealer is formulated with premium acrylic resins that are designed to stop asphalt residues and oils from staining the acrylic coating system.

#950 Primer/Sealer also aids in the adhesion of the acrylic coating to the substrate.

#950 Primer/Sealer should be used as a primer coat over existing granulated asphalt roofing, mastics and coatings where staining of the acrylic coating system is a concern. Use over existing solvent based asphalt mastics and coatings on Western Colloid metal sealing systems.

NOT RECOMMENDED FOR USE OVER SMOOTH ASPHALT EMULSION OR OTHER SMOOTH ASPHALT OR MODIFIED BITUMEN SURFACES.

For increased adhesion to smooth asphalt surfaces or ponding conditions use #970 A2A Bonding Primer.

SCAN FOR
PRODUCT
SPECS



PRIMERS

SCAN FOR
PRODUCT
SPECS



Directions For Use

PREPARATION

Surface must be dry and free of dirt, dust, oil, grease, wax, rust, chalky or loose paint, mildew and any other surface contamination that may inhibit adhesion. It is recommended that the surface be washed prior to the application. Repair any splits, holes or deficiencies in the existing system using #800 or #8000 Elastic Cement or proper sealing compound prior to application.

APPLICATION

Using roller, brush or spray equipment, apply to the properly prepared surface. See Technical Data Sheets for proper rate and amounts. Primers should be allowed to completely cure before the application of the top coating. Mix thoroughly before using. Do not dilute.

CLEAN UP

Wet material and all tools and equipment may be cleaned with water. Rinse tools and equipment with water before using.

PRECAUTIONS

Do not apply Primers when surface or air temperature is below 55o F, or if cold weather, rain or fog is expected within forty-eight hours of application. Primers cures through dehydration. Drying time may vary depending upon wet film thickness, temperature, humidity and air movement. Do not leave Primers in spray hose when not in use. Flush hoses with fresh water.

**READ AND FOLLOW DIRECTIONS CAREFULLY
REFER TO THE LATEST SDS FOR PROPER HANDLING**

NOT RECOMMENDED FOR USE OVER SILICONE COATINGS



800-464-8292 • WesternColloid.com



PB-P305070_23-03-15